


**⚠ WARNING**

**Must read before using this manual
And the various warning label attached!
Attention preservation for future use!**



Operation and Safety Manual

AWPS23.56/AWPS46.79/AWPS46.96

Electric scissor lifts

FOREWORD	3
SAFETY ALERT SYMBOLS AND SAFETY SIGNAL WORDS.....	4
1. SAFETY PRECAUTIONS	5
1.1 GENERAL	5
1.2 PRE-OPERATION	6
1.3 OPERATION	7
1.4 TOWING, LIFTING, AND HAULING	12
1.5 MAINTENANCE	12
2. USER RESPONSIBILITIES, MACHINE PREPARATION & INSPECTION.....	14
2.1 PERSONNEL TRAINING.....	14
2.2 PREPARATION, INSPECTION, AND MAINTENANCE	15
3. USER RESPONSIBILITIES AND MACHINE CONTROLS.....	20
3.1 GENERAL	20
3.2 PERSONNEL TRAINING.....	20
3.3 OPERATING CHARACTERISTICS AND LIMITATIONS.....	22
3.4 CONTROLS AND INDICATORS	22
3.5 SIGNS.....	27
4. MACHINE OPERATION	31
4.1 DESCRIPTION	31
4.2 OPERATION	31
4.3 RAISING AND LOWERING	31
4.4 STEERING.....	34
4.5 DRIVING	34
4.6 PARKING AND STOWING	35
4.7 BATTERY CHARGING.....	36
4.8 PLATFORM LOADING.....	37
4.9 SAFETY PROP	38
4.10 TIE DOWN/LIFT LUGS	38
4.11 LIFTING.....	38
4.12 TOWING	39
5. EMERGENCY PROCEDURES.....	40
5.1 GENERAL	40
5.2 EMERGENCY OPERATION.....	40
6. GENERAL SPECIFICATIONS AND OPERATOR MAINTENANCE.....	42
6.1 INTRODUCTION	42
6.2 OPERATING SPECIFICATIONS.....	42
6.3 CRITICAL STABILITY WEIGHTS	45
6.5 TIRES AND WHEELS	48
Appendix 1 list of wearing parts	49
Appendix 2 Inspection and maintenance records	50

FOREWORD

This manual is a very important tool! Keep it with the machine at all times.

The purpose of this manual is to provide owners, users, operators, lessors, and lessees with the precautions and operating procedures essential for the safe and proper machine operation for its intended purpose.

All of the information reported herein is based on data available at the moment of printing. Our products are constantly being developed and renewed, we reserves the right to modify our own products at any moment without notice and incurring in any sanction. So, it is suggested to always verify possible updates.

SAFETY ALERT SYMBOLS AND SAFETY SIGNAL WORDS



——This is the Safety Alert Symbol. It is used to alert you to the potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death



——INDICATES AN IMMINENTLY HAZARDOUS SITUATION. IF NOT AVOIDED, WILL RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE A RED BACKGROUND.



——INDICATES A POTENTIALITY HAZARDOUS SITUATION. IF NOT AVOIDED, COULD RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE AN ORANGE BACKGROUND.



——INDICATES A POTENTIALITY HAZARDOUS SITUATION. IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY. IT MAY ALSO ALERT AGAINST UNSAFE PRACTICES. THIS DECAL WILL HAVE A YELLOW BACKGROUND.

NOTICE

——AND PERSONNEL SAFETY OR PROTECTION OF PROPERTY DIRECTLY OR INDIRECTLY RELATED INFORMATION OR COMPANY POLICY.



THE ELECTRIC PALLET TRUCK CANNOT BE USED IN POTENTIALLY EXPLOSIVE ATMOSPHERES!



THIS PRODUCT MUST COMPLY WITH ALL SAFETY RELATED BULLETINS. CONTACT NOBLELIFT EQUIPMENT JOINT STOCK CO.,LTD. OR THE LOCAL AUTHORIZED NOBLELIFT REPRESENTATIVE FOR INFORMATION REGARDING SAFETYRELATED BULLETINS WHICH MAY HAVE BEEN ISSUED FOR THIS PRODUCT.

NOTICE

NOBLELIFT EQUIPMENT JOINT STOCK CO.,LTD. SENDS SAFETY RELATED BULLETINS TO THE OWNER OF RECORD OF THIS MACHINE. CONTACT NOBLELIFT EQUIPMENT JOINT STOCK CO.,LTD. TO ENSURE THAT THE CURRENT OWNER RECORDS ARE UPDATED AND ACCURATE.

NOTICE

NOBLELIFT EQUIPMENT JOINT STOCK CO.,LTD. MUST BE NOTIFIED IMMEDIATELY IN ALL INSTANCES WHERE NOBLELIFT PRODUCTS HAVE BEEN INVOLVED IN AN ACCIDENT INVOLVING BODILY INJURY OR DEATH OF PERSONNEL OR WHEN SUBSTANTIAL DAMAGE HAS OCCURRED TO PERSONAL PROPERTY OR THE NOBLELIFT PRODUCT.

For:

- Accident Reporting
- Product Safety Publications
- Current Owner Updates
- Questions Regarding Product Safety
- Standards and Regulations Compliance Information
- Questions Regarding Special Product Applications
- Questions Regarding Product Modifications

Contact:

NOBLELIFT EQUIPMENT JOINT STOCK CO. LTD.
No.528, Jingyi Road Economic Development
Zone, Changxing, Zhejiang, China
Tel:0572-6210811 Fax:0572-6128212
or Your Local NOBLELIFT Office

1. SAFETY PRECAUTIONS

1.1 GENERAL

This section outlines the necessary precautions for proper and safe machine usage and maintenance. In order to promote proper machine usage, it is mandatory that a daily routine is established based on the content of this manual. A maintenance program, using the information provided in this manual and the Service and Maintenance Manual, must also be established by a qualified person and must be followed to ensure that the machine is safe to operate.

The owner/user/operator/lessor/lessee of the machine should not accept operating responsibility until this manual has been read, training is accomplished, and operation of the machine has been completed under the supervision of an experienced and qualified operator.

These sections contain the responsibilities of the owner, user, operator, lessor, and lessee concerning safety, training, inspection, maintenance, application, and operation. If there are any questions with regard to safety, training, inspection, maintenance, application, and operation, please contact NOBLELIFT Industries, Inc.




FAILURE TO COMPLY WITH THE SAFETY PRECAUTIONS LISTED IN THIS MANUAL COULD RESULT IN MACHINE DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

1.2 PRE-OPERATION

Operator Training and Knowledge

- The Operators and Safety Manual must be read in its entirety before operating the machine.



- An operator must not accept operating responsibilities until adequate training has been given by competent and authorized persons.
- Allow only those authorized and qualified personnel to operate the machine who have demonstrated that they understand the safe and proper operation and maintenance of the unit.
- Read, understand, and obey all DANGERS, WARNINGS, CAUTIONS, and operating instructions on the machine and in this manual.
- Ensure that the machine is to be used in a manner which is within the scope of its intended application as determined by NOBLIFT
- All operating personnel must be familiar with the emergency controls and emergency operation of the machine as specified in this manual.
- Read, understand, and obey all applicable employer, local, and governmental regulations as they pertain to your utilization and application of the machine.

Workplace Inspection

- Precautions to avoid all hazards in the work area must be taken by the user before operation of the machine.
- Do not operate or raise the platform from a position on trucks, trailers, railway cars, floating vessels, scaffolds or other equipment unless the application is approved in writing by NOBLIFT.
- Before operation, check work area for overhead hazards such as electric lines, bridge cranes, and other potential overhead obstructions.
- Check floor surfaces for holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards.

- Check the work area for hazardous locations. Do not operate the machine in hazardous environments unless approved for that purpose by NOBLIFT.
- Ensure that the ground conditions are adequate to support the maximum tire load indicated on the tire load decals located on the chassis adjacent to each wheel.
- Do not operate the machine when wind conditions exceed 28 mph (12.5 m/s).
- This machine can be operated in nominal ambient temperatures of 0° F to 104° F (-20°C to 40°C). Consult NOBLIFT to optimize operation outside of this temperature range.

Machine Inspection

- Do not operate this machine until the inspections and functional checks have been performed as specified in Section 2 of this manual.
- Do not operate this machine until it has been serviced and maintained according to the maintenance and inspection requirements as specified in the machine's Service and Maintenance Manual.
- Ensure all safety devices are operating properly. Modification of these devices is a safety violation.

WARNING

MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.

- Do not operate any machine on which the safety or instruction placards or decals are missing or illegible.
- Check the machine for modifications to original components. Ensure that any modifications have been approved by NOBLIFT.
- Avoid accumulation of debris on platform deck. Keep mud, oil, grease, and other slippery substances from footwear and platform deck.

1.3 OPERATION

General

- Do not use the machine for any purpose other than positioning personnel, their tools, and equipment.
- Before operation, the user must be familiar with the machine capabilities and operating characteristics of all functions.
- Never operate a malfunctioning machine. If a malfunction occurs, shut down the

machine. Remove the unit from service and notify the proper authorities.


- Do not remove, modify, or disable any safety devices.
- Never slam a control switch or lever through neutral to an opposite direction. Always return switch to neutral and stop before moving the switch to the next function. Operate controls with slow and even pressure.
- Do not allow personnel to tamper with or operate the machine from the ground with personnel in the platform, except in an emergency.
- Do not carry materials directly on platform railing unless approved by NOBLIFT.
- When two or more persons are in the platform, the operator shall be responsible for all machine operations.
- Always ensure that power tools are properly stowed and never left hanging by their cord from the platform work area.
- Do not assist a stuck or disabled machine by pushing or pulling except by pulling at the chassis tie-down lugs.
- The extension of the platform only in the lowest position to extend the operation.
- Stow scissor arm assembly and shut off all power before leaving machine.
- The machine has according to EN280:2001 + A2:2009 the braking, overload and function testing.

Trip and Fall Hazards

- NOBLIFT Industries, Inc. recommends that all persons in the platform wear a full body harness with a lanyard attached to an authorized lanyard anchorage point while operating this machine. For further information regarding fall protection requirements on NOBLIFT products, contact NOBLIFT Industries, Inc.





- Prior to operation, ensure all gates and rails are fastened and secured in their proper position. Identify the designated lanyard anchorage point(s) at the platform and securely attach the lanyard. Attach only one (1) lanyard per lanyard anchorage point.



- Keep both feet firmly positioned on the platform floor at all times. Never position ladders, boxes, steps, planks, or similar items on unit to provide additional reach for any purpose.
- Never use the scissor arm assembly to gain access to or leave the platform.
- Use extreme caution when entering or leaving platform. Ensure that the scissor arm assembly is fully lowered. Face the machine when entering or leaving the platform. Always maintain “three point contact” with the machine, using two hands and one foot or two feet and one hand at all times during entry and exit.
- Keep oil, mud, and slippery substances cleaned from footwear and the platform floor.

Electrocution Hazards

- This machine is not insulated and does not provide protection from contact or proximity to electrical current.



- Maintain safe clearance from electrical lines, apparatus, or any energized (exposed or insulated) parts in accordance with the Minimum Approach Distance (M.A.D.) as specified in Table 1-1.
- Allow for machine movement and electrical line swaying.

Table 1-1. Minimum Approach Distances (M.A.D.)

Voltage Range (Phase to Phase)	MINIMUM APPROACH DISTANCE in Feet (Meters)
0 to 50KV	10 (3)
Over 50 KV to 200 KV	15 (5)
Over 200 KV to 350 KV	20 (6)
Over 350 KV to 500 KV	25 (8)
Over 500 KV to 750 KV	35 (11)
Over 750 KV to 1000 KV	45 (14)
NOTE: This requirement shall apply except where employer, local or governmental regulations are more stringent.	


- Maintain a clearance of at least 10 ft (3 m) between any part of the machine and its occupants, their tools, and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less.
- The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment.



DO NOT MANEUVER MACHINE OR PERSONNEL INSIDE PROHIBITED ZONE (M.A.D.). ASSUME ALL ELECTRICAL PARTS AND WIRING ARE ENERGIZED UNLESS KNOWN OTHERWISE

Tipping Hazards

- Ensure that the ground conditions are adequate to support the maximum tire load indicated on the tire load decals located on the chassis adjacent to each wheel. Do not travel on unsupported surfaces.
- The user should be familiar with the driving surface before driving. Do not exceed the allowable sideslope and grade




while driving.

- Do not elevate platform or drive with platform elevated while on or near a sloping, uneven, or soft surface. Ensure machine is positioned on a firm, level and smooth surface before elevating platform or driving with the platform in the elevated position.
- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.
- Never exceed the maximum work load as specified on the platform. Keep all loads within the confines of the platform, unless authorized by NOBLIFT.
- Keep the chassis of the machine a minimum of 0.6 m (2 ft) from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards at the ground level.
- Never attempt to use the machine as a crane. Do not tie off machine to any adjacent structure. Never attach wire, cable, or any similar items to platform.
- Do not cover the platform sides or carry large surface-area items in the platform when operating outdoors. The addition of such items increases the exposed wind area of the machine.
- Do not increase the platform size with unauthorized deck extensions or attachments.
- If scissor arm assembly or platform is caught so that one or more wheels are off the ground, all persons must be removed before attempting to free the machine. Use cranes, forklift trucks, or other appropriate equipment to stabilize machine and remove personnel.

Crushing and Collision Hazards

- Approved head gear must be worn by all operating and ground personnel.
- Keep hands and limbs out of the scissor arm assembly during operation.
- Watch for obstructions around machine and overhead when driving. Check clearances above, on sides, and bottom of platform when lifting or lowering platform.



- During operation, keep all body parts inside platform railing.
- Always post a lookout when driving in areas where vision is obstructed.
- Keep non-operating personnel at least 1.8 m (6 ft) away from machine during all driving operations.
- Under all travel conditions, the operator must limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors causing hazards of collision or injury to personnel.
- Be aware of stopping distances in all drive speeds. When driving in high speed, switch to low speed before stopping. Travel grades in low speed only.
- Do not use high speed drive in restricted or close quarters or when driving in reverse.
- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Ensure that operators of other overhead and floor level machines are aware of the aerial work platform's presence. Disconnect power to overhead cranes. Barricade floor area if necessary.
- Avoid operating over ground personnel. Warn personnel not to work, stand, or walk under a raised platform. Position barricades on floor as necessary.

1.4 TOWING, LIFTING, AND HAULING

- Never allow personnel in platform while towing, lifting, or hauling.
- This machine should not be towed, except in the event of emergency, malfunction, power failure, or loading/unloading. Refer to emergency towing procedures.
- Ensure platform is fully retracted and completely empty of tools prior to towing, lifting or hauling.
- When lifting machine with a forklift, position forks only at designated areas of the machine. Lift with a forklift of adequate capacity.
- Refer to Section 4 for lifting information.

1.5 MAINTENANCE

General

This section contains general safety precautions which must be observed during maintenance of this machine. Additional precautions to be observed during machine maintenance are inserted at the appropriate points in this manual and in the Service and Maintenance Manual. It is of utmost importance that maintenance personnel pay strict attention to these precautions to avoid possible injury to personnel or damage to the machine or property. A maintenance program must be established by a qualified person and must be followed to ensure that the machine is safe.

Maintenance Hazards

- Shut off power to all controls and ensure that all operating systems are secured from inadvertent motion prior to performing any adjustments or repairs.
- Never work under an elevated platform until it has been fully lowered to the full down position, if possible, or otherwise supported and restrained from movement with appropriate safety props, blocking, or overhead supports.
- Always relieve hydraulic pressure from all hydraulic circuits before loosening or removing hydraulic components.
- Always disconnect batteries when servicing electrical components or when performing welding on the machine.
- Shut down the engine (if equipped) while fuel tanks are being filled.
- Ensure replacement parts or components are identical or equivalent to original parts or components.
- Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. Ensure adequate support is provided when raising components of the machine.
- Remove all rings, watches, and jewelry when performing any maintenance. Do not wear loose fitting clothing or long hair unrestrained which may become caught or entangled in equipment.
- Use only clean approved non-flammable cleaning solvents.
- Never alter, remove, or substitute any items such as counterweights, tires, batteries, platforms or other items that may reduce or affect the overall weight or stability of the machine.
- Reference the Service and Maintenance Manual for the weights of critical stability items.

WARNING

MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.

Battery Hazards

- Always disconnect batteries when servicing electrical components or when performing welding on the machine.
- Do not allow smoking, open flame, or sparks near battery during charging or servicing.
- Do not contact tools or other metal objects across the battery terminals.
- Always wear hand, eye, and face protection when servicing batteries. Ensure that battery acid does not come in contact with skin or clothing.

WARNING

BATTERY FLUID IS HIGHLY CORROSIVE. AVOID CONTACT WITH SKIN AND CLOTHING AT ALL TIMES. IMMEDIATELY RINSE ANY CONTACTED AREA WITH CLEAN WATER AND SEEK MEDICAL ATTENTION.

- Charge batteries only in a well ventilated area.
- Avoid overfilling the battery fluid level. Add distilled water to batteries only after the batteries are fully charged.

2. USER RESPONSIBILITIES, MACHINE PREPARATION & INSPECTION

2.1 PERSONNEL TRAINING

The aerial platform is a personnel handling device; so it is necessary that it be operated and maintained only by trained personnel.

Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

Operator Training

Operator training must cover:

1. Use and limitations of the controls in the platform and at the ground, emergency controls and safety systems.
2. Control labels, instructions, and warnings on the machine.

3. Rules of the employer and government regulations.
4. Use of approved fall protection device.
5. Enough knowledge of the mechanical operation of the machine to recognize a malfunction or potential malfunction.
6. The safest means to operate the machine where overhead obstructions, other moving equipment, and obstacles, depressions, holes, drop-offs.
7. Means to avoid the hazards of unprotected electrical conductors.
8. Specific job requirements or machine application.

Training Supervision

Training must be done under the supervision of a qualified person in an open area free of obstructions until the trainee has developed the ability to safely control and operate the machine.

Operator Responsibility

The operator must be instructed that he/she has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site.

2.2 PREPARATION, INSPECTION, AND MAINTENANCE

The following table covers the periodic machine inspections and maintenance recommended by NOBLIFT Industries, Inc.. Consult local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as necessary when the machine is used in a harsh or hostile environment, if the machine is used with increased frequency, or if the machine is used in a severe manner.

NOTICE

NOBLIFT INDUSTRIES, INC. RECOGNIZES A FACTORY-CERTIFIED SERVICE TECHNICIAN AS A PERSON WHO HAS SUCCESSFULLY COMPLETED THE NOBLIFT SERVICE TRAINING SCHOOL FOR THE SPECIFIC NOBLIFT PRODUCT MODEL.


Table 2-1. Inspection and Maintenance Table

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Before using each day; or whenever there's an Operator change	User or Operator	User or Operator	Operator and Safety Manual
Pre-Delivery Inspection (See Note)	Before each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified Mechanic	Service and Maintenance Manual and applicable inspection form
Frequent Inspection	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or Purchased used.	Owner, Dealer, or User	Qualified Mechanic	Service and Maintenance Manual and applicable inspection form
Annual Machine Inspection	Annually, no later than 13 months from the date of prior inspection.	Owner, Dealer, or User	Factory Certified Service Technician (Recommended)	Service and Maintenance Manual and applicable inspection form
Preventative Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified Mechanic	Service and Maintenance Manual
NOTE: Inspection forms are available from NOBLIFT. Use the Service and Maintenance Manual to perform inspections.				

Pre-Start Inspection

The Pre-Start Inspection should include each of the following:

- 1. Cleanliness** – Check all surfaces for leakage (oil, fuel, or battery fluid) or foreign objects. Report any leakage to the proper maintenance personnel.
- 2. Structure** - Inspect the machine structure for dents, damage, weld or parent metal cracks or other discrepancies.



Parent Metal Crack



Weld Crack

- 3. Decals and Placards** – Check all for cleanliness and legibility. Make sure none of the decals and placards are missing. Make sure all illegible decals and placards are cleaned or replaced.
- 4. Operation and Safety Manuals** – Make sure a copy of the Operator and Safety Manual.
- 5. “Walk-Around” Inspection** – Refer to Figure 2-1

6. **Battery** – Charge as required.
7. **Fuel** (Combustion Engine Powered Machines) – Add the proper fuel as necessary.
8. **Engine Oil Supply** (If equipped) - Ensure the engine oil level is at the Full mark on the dipstick and the filler cap is secure.
9. **Fluid Levels** – Check the hydraulic oil level. Ensure hydraulic oil is added as required.
10. **Accessories/Attachments** - Reference the Operator and Safety Manual of each attachment or accessory installed upon the machine for specific inspection, operation, and maintenance instructions.
11. **Function Check** – Once the “Walk-Around” Inspection is complete, perform a functional check of all systems in an area free of overhead and ground level obstructions. Refer to Section 4 for more specific operating instructions.

Function Check

Perform the Function Check as follows:

1. From the ground control console with no load in the platform:
 - a. Check that all guards protecting the function control switches and controllers are in place.
 - b. Operate all functions and check all limiting and cutout switches.
 - c. Check manual descent.
 - d. Ensure that all machine functions are disabled when the Emergency Stop Button is depressed.
2. From the platform control console:
 - a. Ensure that the control console is firmly secured in the proper location.
 - b. Check that all guards protecting the function control switches and controllers are in place.
 - c. Operate all functions and check all limiting and cutout switches.
 - d. Ensure that all machine functions are disabled when the Emergency Stop Button is depressed.
3. With the platform in the transport (stowed) position:
 - a. Drive the machine on a grade, not to exceed the rated gradeability, and stop to ensure the brakes hold.
 - b. Check the tilt indicator light to ensure proper operation. The light should be

illuminated when tilted.

Table 2-2. Tilt vs. Height

Model	Tilt Setting (front to back)	Tilt Setting (side to side)	Maximum Deck Elevation	
			Feet	Meters
AWPS23.56	2	2	18.4(Full)	5.6
AWPS46.79	2	2	26 (Full)	7.9
AWPS46.96	2	2	31.5 (Full)	9.6

Table 2-3. High Drive Speed Cutout Height

Model	High Drive Speed Cutout Height	
AWPS23.56	54 in	1.4m
AWPS46.79	76 in	1.9m
AWPS46.96	76 in	1.9m




Figure 2-1. Daily Walk-Around Inspection - Sheet 1 of 3

General

Begin the “Walk-Around Inspection” at Item 1, as noted on the diagram. Continue Left (counterclockwise viewed from top) checking each item in sequence for the conditions listed in the following checklist.

⚠ WARNING


TO AVOID POSSIBLE INJURY, BE SURE MACHINE POWER IS “OFF” DURING “WALK-AROUND INSPECTION”.

NOTICE

DO NOT OVERLOOK VISUAL INSPECTION OF CHASSIS UNDERSIDE. CHECKING THIS AREA OFTEN RESULTS IN DISCOVERY OF CONDITIONS WHICH COULD CAUSE EXTENSIVE MACHINE DAMAGE.

NOTE: *On each item, make sure there are no loose or missing parts, that they are securely fastened, and that no visible damage exists in addition to any other criteria mentioned.*

1. Platform Control Console - Placard secure and legible, control lever and switches return to neutral, control lever lock and emergency stop switch function properly, manual in storage box.
2. Steer Cylinder - See Note
3. Spindle, Tie Rod, Drive Motor and Steer Linkage (left front) - See Note
4. Wheels and Tires - Properly secured, no missing lug nuts. Refer to Section 6, Tires and Wheels. Inspect wheels for damage and corrosion.
5. Pothole Protection System - See Note
6. Battery Compartment - Proper electrolyte level.
7. Proximity Switch - See Note
8. Manual Descent - See Note
9. Beacon - See Note
10. Ground Controls - Placard secure and legible, control switches return to neutral position, emergency stop switch functions properly. Control markings legible.
11. Rotary Angle Switch - See Note
12. Hydraulic Pump/Motor, Control Valve Installation – No unsupported wires or hoses; no damaged or broken wires - See Note
13. Lift Cylinder - See Note
14. Spindle, Tie Rod, Drive Motor and Steer Linkage (left front) - See Note
15. Sizzor Arms, Pivot Pins and Sliding Wear Pads (Not Shown) - See Note
16. Platform/Handrail Installation (Not Shown) - See Note



- 1、 Pothole Switch (Typical on opposite side of machine)

Figure 2-2. Switch Location - 2 of 2

3. USER RESPONSIBILITIES AND MACHINE CONTROLS

3.1 GENERAL

NOTICE

SINCE THE MANUFACTURER HAS NO DIRECT CONTROL OVER MACHINE APPLICATION AND OPERATION, CONFORMANCE WITH GOOD SAFETY PRACTICES IN THESE AREAS IS THE RESPONSIBILITY OF THE USER AND HIS OPERATING PERSONNEL.

This section provides the necessary information needed to understand control functions. Included in this section are the operating characteristics and limitations, and functions and purposes of controls and indicators. It is important that the user read and understand the proper procedures before operating the machine. These procedures will aid in obtaining optimum service life and safe operation.

3.2 PERSONNEL TRAINING

The scissor lift is a personnel handling device; therefore, it is essential that it be operated and maintained only by authorized personnel who have demonstrated that they understand the proper use and maintenance of the machine. It is important that all personnel who are assigned to and responsible for the operation

and maintenance of the machine undergo a thorough training program and check out period in order to become familiar with the characteristics prior to operating the machine.

Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not be permitted to operate the machine.

Operator Training

Operator training must include instruction in the following:

1. Use and limitations of the platform controls, ground controls, emergency controls and safety systems.
2. Knowledge and understanding of this manual and of the control markings, instructions and warnings on the machine itself.
3. Knowledge and understanding of all safety work rules of the employer and of Federal, State and Local Statutes, including training in the recognition and avoidance of potential hazards in the work place; with particular attention to the work to be performed.
4. Proper use of all required personnel safety equipment.
5. Sufficient knowledge of the mechanical operation of the machine to recognize a malfunction or potential malfunction.
6. The safest means to operate near overhead obstructions, other moving equipment, obstacles, depressions, holes, drop-offs, etc. on the supporting surface.
7. Means to avoid the hazards of unprotected electrical conductors.
8. Any other requirements of a specific job or machine application.

Training Supervision

Training must be done under the supervision of a qualified operator or supervisor in an open area free of obstructions until the trainee has developed the ability to safely control a scissor lift in congested work locations.

Operator Responsibility

The operator must be instructed that he has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site and to request further information from his supervisor or NOBLIFT Distributor before proceeding.

NOTE: *Manufacturer or Dealer will provide qualified persons for training assistance with first unit(s) delivered and thereafter as requested by user or his personnel.*

3.3 OPERATING CHARACTERISTICS AND LIMITATIONS

General

A thorough knowledge of the operating characteristics and limitations of the machine is always the first requirement for any user, regardless of user's experience with similar types of equipment.

Placards

Important points to remember during operation are provided at the control stations by DANGER, WARNING, CAUTION, IMPORTANT and INSTRUCTION placards. This information is placed at various locations for the express purpose of alerting personnel of potential hazards constituted by the operating characteristics and load limitations of the machine. See foreword for definitions of the above placards.

Capacities

Raising platform above horizontal with or without any load in platform, is based on the following criteria:

1. Machine is positioned on a smooth, firm and level surface.
2. Load is within manufacturer's rated capacity.
3. All machine systems are functioning properly.

Stability

This machine, as originally manufactured by NOBLIFT and operated within its rated capacity on a smooth, firm and level supporting surface, provides a stable aerial platform for all platform positions.

3.4 CONTROLS AND INDICATORS

Ground Control Station



DO NOT OPERATE FROM GROUND CONTROL STATION WITH PERSONNEL IN THE PLATFORM EXCEPT IN AN EMERGENCY.

PERFORM AS MANY PRE-OPERATIONAL CHECKS AND INSPECTIONS FROM THE GROUND CONTROL STATION AS POSSIBLE.

NOTE: *When the machine is shut down for overnight parking or battery charging, the emergency stop and power select switches must be positioned to off to prevent draining the batteries.*




Figure 3-1. AWPS4679/AWPS4696 Ground Control Station

- 1、 Emergency Stop Switch** - A two-position, red, mushroom- shaped emergency stop switch, when positioned to ON with the power selector switch positioned to ground, furnishes operating power to the ground control station. In addition, the switch can be used to turn off power to the function controls in the event of an emergency. Power is turned on by pulling the switch out (on), and is turned off by depressing switch.
- 2、 Platform Lift/Lower Switch** - A three position, momentary contact Lift control switch provides raising and lowering of the platform when positioned to up or down.
- 3、 Platform/Ground Control Switch** - A three position, key-operated power select switch supplies operating power to the platform or ground controls, as selected. When positioned to platform, the switch provides power to the emergency stop switch at the platform controls. When positioned to ground, the switch provides power to the ground control. The ground control emergency stop switch provides power to the key switch. With the power select switch in the center off position, power is shut off to both platform and ground controls.
- 4、 The brakes release button (traction mode selection button)** - Key switch must be chosen to chassis operation mode, and the platform dropped to its lowest level, press the switch, the vehicle brake release
- 5、 LED-indicator light**-when the machine was something wrong, this light will twinkle
- 6、 LED-indicator light**-when the machine was something wrong, this light will twinkle




Figure 3-2. AWPS2356 Ground Control Station

- 1. The brakes release button (traction mode selection button)** - Key switch must be chosen to chassis operation mode, and the platform dropped to its lowest level, press the switch, the vehicle brake release
- 2. Platform lift switch** - Pressing this switch, the platform to go up.
- 3. Platform drop switch** - Pressing this switch, the platform to go down.
- 4. Platform/Ground Control Switch** - A three position, key-operated power select switch supplies operating power to the platform or ground controls, as selected.
When positioned to platform, the switch provides power to the emergency stop switch at the platform controls. When positioned to ground, the switch provides power to the ground control. The ground control emergency stop switch provides power to the key switch. With the power select switch in the center off position, power is shut off to both platform and ground controls.
- 5. Emergency Stop Switch** - A two-position, red, mushroom- shaped emergency stop switch, when positioned to ON with the power selector switch positioned to ground, furnishes operating power to the ground control station. In addition, the switch can be used to turn off power to the function controls in the event of an emergency. Power is turned on by pulling the switch out (on), and is turned off by depressing switch.

PLATFORM CONTROL STATION




Figure 3-3. AWPS4679/AWPS4696 Platform Control Station

- 1、 Emergency Stop Switch** - A two-position, red, mushroom-shaped emergency stop switch functions to provide power to the platform control station and also to turn off power to the platform function controls in the event of an emergency. With the Power selector switch positioned to platform, power is turned on by pulling the switch out (on), and is turned off by pushing the switch in (off).
- 2、 Control Pole** - it used to control three function: lift、steer、drive. After selecting one of the function, control this switch to use the machine.
- 3、 Lift/Drive Select** - This toggle switch is used to select either drive or lift.
- 4、 LED-indicator light**-when the machine was something wrong, this light will twinkle
- 5、 Meter Display** - to display a series of state in present of machine.
- 6、 Horn** - This push-button switch, when activated, permits the operator to warn jobsite personnel when the machine is operating in the area.
- 7、 LED-indicator light**-when the machine was something wrong, this light will twinkle

⚠ CAUTION

IF THE TILT INDICATOR WARNING LIGHT OR HORN IS ON WHEN PLATFORM IS RAISED, LOWER PLATFORM COMPLETELY, THEN REPOSITION MACHINE SO THAT IT IS LEVEL BEFORE RAISING

PLATFORM.

NOTE: machines are equipped with a tilt interlock which cuts out drive and lift up functions when chassis is on a slope greater than what is allowable for the machine and the platform is elevated.

⚠ CAUTION

DO NOT “LOWER” WITHOUT COMPLETELY RETRACTING THE PLATFORM EXTENSION

⚠ CAUTION

DO NOT OPERATE MACHINE IF HIGH DRIVE SPEED OPERATES WHEN PLATFORM IS RAISED ABOVE THE STOWED POSITION.




Figure 3-4. AWPS2356 Platform Control Station

1.Lift/Drive Select - This toggle switch is used to select either drive or lift.

2. Horn - This push-button switch, when activated, permits the operator to warn jobsite personnel when the machine is operating in the area.

3. Turtle speed / rabbit speed selection switch - the toggle switch for selecting turtle speed forward and backward or forward and backward rabbit speed, choose a function, the switch must be moved to the correct direction to start the function.

4. Meter Display - to display a series of state in present of machine.

5. Control Pole - it used to control three function: lift、steer、drive. After selecting one of the function, control this switch to use the machine.

6. Emergency Stop Switch - A two-position, red, mushroom-shaped emergency stop switch functions to provide power to the platform control station and also to turn off power to the platform function controls in the event of an emergency. With the Power selector switch positioned to platform, power is turned on by pulling the switch out (on), and is turned off by pushing the switch in (off).

3.5 SIGNS




Figure 3-4 ID-plate

- 1 this product allows a maximum wind speed
- 2 this product model
- 3 this product rated load
- 4 the product is rated occupant number
- 5 this product is rated equipment quality
- 6 this product allows a maximum hand operating force
- 7 the product serial number
- 8 this product allows the maximum lateral inclination
- 9 this product allows the maximum slope
- 10 the product serial number
- 11 of the weight of the total product



	Please read the operation manual		Risk of electric shock
	Warning		To maintain the required clearance

Figure 3-5 Warning signs and meaning





 MAX=0m/s	Maximum wind speed is zero	 MAX=12.5m/s	The maximum allowed speed
 MAX = 200N	The maximum allowed hand operating force		Squeeze collision risk
	Safety belt fixed point		Breaking pressure hazard
 MAX 460 kg= ♂♂ +300kg MAX 113 kg= ♂ +33kg	The maximum allowable load	 1207007	Squeeze the hand of danger

Figure 3-5 Warning signs and meaning




Figure 3-6 The position of the label




Figure 3-6 The position of the label legend

4. MACHINE OPERATION

4.1 DESCRIPTION

This machine is a self-propelled aerial work platform on top of an elevating 'scissor' mechanism. The Scissor Lift's intended purpose is to position personnel with their tools and supplies at positions above ground level. The machine can be used to reach work areas located above machinery or equipment positioned at ground level.

The Scissor Lift has a primary operator Control Station in the platform. From this Control Station, the operator can drive and steer the machine in both forward and reverse directions, raise and lower the platform and, if equipped, operate the powered deck extension. The machine has a Ground Control Station which will override the Platform Control Station. Ground Controls operate lift up and down. Ground Controls are to be used only in an emergency to lower the platform to the ground should the operator in the platform be unable to do so.

NOTE: All platform extension capacities are 250 lb (120 kg).

4.2 OPERATION

Platform/Ground Select Switch

The power selector switch functions to direct electrical power to the desired control station. With the switch in the ground position, power is supplied to the emergency stop switch at the ground control station. When the switch is in the platform position, power is supplied to the emergency stop switch at the platform control station. The switch should be in the off position when parking the machine overnight.

Emergency Stop Switch

This switch, when in the on (out) position, provides electrical power to the ground controls or platform controls, as applicable. In addition, the switch can be used to turn off power (push the switch IN) to the function controls in the event of an emergency.

4.3 RAISING AND LOWERING



**ONLY RAISE PLATFORM ON A FIRM, LEVEL AND SMOOTH SURFACE
FREE OF OBSTRUCTIONS AND HOLES.**

NOTE: When selecting between the Lift/Drive functions, the controller must be in the neutral position for 3 seconds before the function change is effective. The machine is inoperable at this point.

Raising

1. If the machine is shut down, place the power selector switch to the desired position (platform or ground).
2. Position the applicable emergency stop switch to the "ON" position.
3. If operating from the ground controls, position the lift switch to up and hold until desired elevation is achieved. If operating from the platform controls, select lift function, squeeze and hold the red trigger switch, move the controller backward (up) and hold until desired elevation is reached. The lift switch works in conjunction with the enable switch. Releasing the trigger switch will stop the function being operated.

Lowering



ENSURE SCISSOR ARM AREA IS FREE OF PERSONNEL PRIOR TO LOWERING PLATFORM.

NOTE: The machine is equipped with a descent alarm which will sound as the platform is being lowered (CE Optional).

If operating from the ground controls, position the lift switch to down and hold until desired elevation is achieved or until platform is fully lowered. If operating from the platform controls, select lift function squeeze the red trigger switch and push the controller forward (down) and hold until desired elevation is reached or until platform is fully lowered. The lift switch works in conjunction with the enable switch. Releasing the trigger switch will stop the function being operated.

Arm Guards (If equipped)

If the machine is equipped with arm guards, the platform will stop lowering and an alarm will sound once it has reached a preset height. At this point, the trigger switch and controller must be released before the lowering function can begin again.



DO NOT 'LOWER' WITHOUT COMPLETELY RETRACTING THE PLATFORM EXTENSION.

Platform Extension

The machine is equipped with a mechanically extendable deck, giving the operator better access to worksites. On the AWPS23.56 this extension adds 3 ft (0.9 m) and on the AWPS46.79 and AWPS46.96 the extension adds 4 ft (1.2 m) to the front of the platform. To extend the deck, pull out handles from latch and swing up, then use the handles and handrail to push the extendable deck out. To retract the deck, pull out the handles from latch and swing up, use the handles and handrail to pull and retract the deck. Be sure the handles are in place after the deck is

retracted. Maximum capacity of the deck extension is 250 lbs (120 kg).

⚠ WARNING

Extension of the platform in the closed or extended must use this handle lock.

Fold-Down Rails

⚠ WARNING

DO NOT RAISE PLATFORM WITH RAILS FOLDED DOWN. THE RAILS MUST BE IN THE UPRIGHT POSITION AND PROPERLY PINNED WHEN RAISING THE PLATFORM.

NOTE: *The rails must only be folded down when the machine is in the stowed (fully lowered) position.*

NOTE: *Ensure that the drywall gate at the rear of the machine is up and locked in position. Platform control box should be removed and placed on the platform with rails folded down.*

1. To fold down the rails, remove the 4 bail pins at the two front corners and center of the rails.
2. Taking a firm hold on the top rails, carefully push forward and lower until the top rail rests on the middle rail.

⚠ WARNING

AFTER THE RAILS HAVE BEEN FOLDED DOWN, USE EXTREME CAUTION WHEN EXITING AND ENTERING THE PLATFORM.

3. To raise the rails back to the upright position, firmly pull the rails toward the back of the machine and replace the bail pins into the rails. Return drywall gate to the lowered position.



4.4 STEERING

To steer the machine, the thumb operated steer control switch on the controller handle is positioned to the right for traveling right, or to the left for traveling left. When released, the switch will return to the center-off position and the wheels will remain in the previously selected position. To return the wheels to the straightened position, the switch must be activated in the opposite direction until the wheels are centered.

4.5 DRIVING

⚠ WARNING

DO NOT DRIVE WITH PLATFORM RAISED EXCEPT ON A SMOOTH, FIRM AND LEVEL SURFACE FREE OF OBSTRUCTIONS AND HOLES.


TO AVOID LOSS OF TRAVEL CONTROL OR UPSET ON GRADES AND SIDESLOPES, DO NOT DRIVE MACHINE ON GRADES OR SIDESLOPES EXCEEDING THOSE SPECIFIED. REFERENCE FIGURE 4-1., GRADE AND SIDESLOPE.

Driving Forward

1. Place power selector switch at ground control station to "Platform."
2. Position emergency stop switch at platform control station to "On" position.
3. Select "Drive" on the drive/lift select switch.
4. Squeeze controller (joystick), depressing red trigger on front of joystick, and move joystick forward for duration of travel. The drive system is proportional so for additional drive speed, push the joystick further in the direction of travel. Releasing the trigger will stop the function being operated.

Driving in Reverse

1. Position power selector switch at ground control station to "Platform."
2. Position emergency stop switch at platform control station to "On" position.
3. Squeeze joystick, depressing red trigger on front of joystick, and move joystick backward (reverse) for duration of travel. The drive system is proportional so for additional drive speed, push the joystick further in the direction of travel. Releasing the trigger will stop the function being operated.



4.6 PARKING AND STOWING

Park and stow the machine as follows:

1. Drive the machine to a reasonably well-protected and well-ventilated area.
2. Ensure the platform is fully lowered.
3. Position the emergency stop switch to the "Off" position.
4. If necessary, cover the instruction placards, caution and warning decals so that they will be protected from hostile environment.
5. Chock at least two wheels when parking the machine for an extended period of time.
6. Turn the power selector switch to "Off" and remove the key to disable the machine and prevent unauthorized use. The platform control station can also be secured to it's mounting plate, see Figure 4-2.




Figure 4-2. Securing Control Station to Platform

4.7 BATTERY CHARGING

Operation

NOTE: *Be sure that machine is parked in a well ventilated area before charging begins.*



ONLY PLUG THE CHARGER INTO A PROPERLY INSTALLED AND GROUNDED OUTLET. DO NOT USE GROUND ADAPTORS OR MODIFY PLUG. DO NOT TOUCH NON-INSULATED PORTION OF OUTPUT CONNECTOR OR NON-INSULATED BATTERY TERMINAL.

ALWAYS DISCONNECT THE AC SUPPLY BEFORE MAKING OR BREAKING THE CONNECTIONS TO THE BATTERY BEFORE CHARGING.

DO NOT OPEN OR DISASSEMBLE CHARGER.

DO NOT OPERATE CHARGER IF THE AC SUPPLY CORD IS DAMAGED OR IF THE CHARGER HAS RECEIVED A SHARP BLOW, BEEN DROPPED, OR OTHERWISE DAMAGED IN ANY WAY.

The battery charger receptacle is located at the right rear of the machine near the ground control panel.

1. Connect the charger to a grounded outlet.
2. On the Battery Charger, the charger will automatically turn on and go through a short LED indicator self-test. All LED's will flash in an up and down sequence for two seconds.
3. The batteries are fully charged when green light on the battery charger status panel is illuminated.

NOTE: *If the charger is left plugged in, the charger will automatically restart a complete charge cycle if the batteries voltage drops below a minimum voltage or 30 days has elapsed.*

Battery Charger Fault Codes

If a fault occurred during charging, the red "Fault" LED will flash with a code. The number of flashes corresponds to the error. Refer to Table 4-1, Battery Charger Flash Codes.

Table 4-1. Battery Charger Flash Codes

Flash(s)	Fault	Fault Removal
1	Battery voltage high	Auto-recover - Indicates a high battery pack voltage
2	Battery voltage low	Auto-recover - Indicates either a battery pack failure, battery pack not connected to charger or battery volts per cell is less than 0.5 VDC. Check the battery pack and connections
3	Charge time-out	Indicates the batteries did not charge in the allowed time. This could occur if the batteries are a larger capacity than the algorithm is intended for or if the batteries are damaged old or in poor condition.
4	Check battery	Indicates the batteries could not be trickle charged up to the minimum voltage per cell level required for the charge to be started.
5	Over-temperature	Auto-recover - Indicates charger has shut down due to high internal temperature
6	QuiQ fault	Indicates that the battery will not accept charge current, or an internal fault has been detected in the charger. This fault will nearly always be set within the first 30 seconds of operation. Once it has been determined that the batteries and connections are not faulty and fault 6 is again displayed after interrupting AC power for at least 10 seconds, the charger must be brought to a qualified service depot.

4.8 PLATFORM LOADING

The platform maximum rated load capacity is shown on a placard located on the platform and is based upon the following criteria:

1. The machine is positioned on a firm, uniform surface.
2. All braking devices are engaged.
3. Refer to Section 6 for the maximum platform capacity.

NOTE: *It is important to remember that the load should be evenly distributed on the platform. The load should be placed near the center of the platform when possible.*

4.9 SAFETY PROP

⚠ CAUTION

THE SAFETY PROP MUST BE USED WHENEVER MAINTENANCE PERFORMED ON THE MACHINE REQUIRES THE SCISSOR ARMS TO BE RAISED AND ONLY WITH NO LOAD IN THE PLATFORM.

To engage the safety prop, raise the platform, swing the safety prop from its stowed position located on the right side of the machine. Lower the platform until the safety prop rests on the designated safety prop rest.

To store the safety prop, raise the platform, swing the safety prop around and restore it back to its stowed position.

4.10 TIE DOWN/LIFT LUGS

When transporting the machine, the platform extension must be fully retracted and the platform fully lowered in the stowed mode with the machine securely tied down to the truck or trailer deck. There are two tie-down/lift lugs located at the rear of the machine for lifting and tying down. There is a single tie-down lug at the front of the machine. This lug is designed for tying down only. Do not attempt to lift machine from the front lug.

⚠ CAUTION

LIFTING THE MACHINE FROM THE SIDES USING A FORK TRUCK IS NOT RECOMMENDED BY NOBLIFT. IN THE EVENT THAT THE MACHINE NEEDS TO BE LIFTED FROM THE SIDES CAUTION MUST BE USED TO AVOID JAMMING THE POT HOLE PROTECTION BARS UP AGAINST THE FRAME.

EVERY TIME THE MACHINE IS LIFTED FORM THE SIDE, BE SURE AND TEST THE POT HOLE PROTECTION SYSTEM BEFORE THE MACHINE IS PUT BACK INTO OPERATION.

4.11 LIFTING

In the event that the machine must be lifted, there is a forklift pocket located at the rear of the machine. The machine can also be lifted using a proper spreader bar and straps/chains. Reference Figure 4-3., Lifting and Tie Down Diagram.




Figure 4-3. Lifting and Tie Down Diagram

4.12 TOWING

It is not recommended that this machine be towed, except in the event of an emergency such as a machine malfunction or a total machine power failure.

NOTE: *The machine may be equipped with a remote electric brake release, a push button electric brake release, or both styles of electric brake release.*

WARNING

RUNAWAY VEHICLE/MACHINE HAZARD. MACHINE HAS NO TOWING BRAKES, TOWING VEHICLE MUST BE ABLE TO CONTROL MACHINE AT ALL TIMES. ON-HIGHWAY TOWING NOT PERMITTED. FAILURE TO FOLLOW INSTRUCTIONS COULD CAUSE SERIOUS INJURY OR DEATH.

MAXIMUM TOWING SPEED 5 MPH (8 KPH) FOR NO FURTHER THAN 60 FEET (18 M).

MAXIMUM TOWING GRADE 25%.

Remote Electric Brake Release

1. Chock wheels or secure machine with tow vehicle.
2. Pull the emergency stop switch out and position the keyswitch to ground mode.
3. The brake release cable hangs on a hook in the battery compartment on the opposite side of the ground control panel.
4. Locate brake release plug near the analyzer plug at the left front corner of the machine and plug the release cable into the plug.
5. Depress switch to release brakes.
6. When finished towing; release switch, unplug release switch and return brake switch to the proper storage area in the battery compartment.

Push Button Electric Brake Release

NOTE: *The push button electric brake release is located on the right side of the machine just forward of the ground control box.*

1. Chock wheels or secure machine with tow vehicle.
2. Pull the emergency stop switch out and position the keyswitch to ground mode.
3. Push the button once to release the brakes.
4. To reset the brakes, push the button again, or push in the emergency stop switch, or take the ground control keyswitch out of the ground mode position.

5. EMERGENCY PROCEDURES

5.1 GENERAL

This section provides information on the procedures to be followed and on the systems and controls to be used in the event an emergency situation is encountered during machine operation. Prior to operation of the machine and periodically thereafter, the entire operating manual, including this section, should be reviewed by all personnel whose responsibilities include any work or contact with the machine.

Emergency Stop Switch

These large red buttons, one located at the Ground Control Station and one at the Platform Control Station, will immediately stop the machine when depressed.

WARNING

CHECK MACHINE DAILY TO MAKE SURE EMERGENCY STOP BUTTON IS IN PLACE AND THAT GROUND CONTROL INSTRUCTIONS ARE IN PLACE AND LEGIBLE. GROUND CONTROL STATION

The Ground Control Station is located on the left side of the machine frame. The controls on this panel provide the means for overriding the platform controls and for controlling the platform lift up and down functions from the ground. Place the power select switch in the ground position and operate the lift switch to lift up or down.

Manual Descent

The manual descent valve is used, in the event of total power failure, to lower the platform using gravity. The manual descent handle is located at the rear of the machine, above the left rear wheel. The handle is connected, by a cable, to the manual descent valve on the lift cylinder. Pulling the manual descent handle opens the valve spool, lowering the platform.

5.2 EMERGENCY OPERATION

Use of Ground Controls

NOTICE

KNOW HOW TO USE THE GROUND CONTROLS IN AN EMERGENCY SITUATION.

Ground personnel must be thoroughly familiar with the machine operating characteristics and the ground control functions. Training should include operation of the machine, review and understanding of this section and hands-on operation of the controls in simulated emergencies.

Operator Unable to Control Machine

1. Operate the machine from ground controls ONLY with the assistance of other personnel and equipment (cranes, overhead hoists, etc.) as may be required to safely remove the danger or emergency condition.
2. Other qualified personnel on the platform may use the platform controls. DO NOT CONTINUE OPERATION IF CONTROLS DO NOT FUNCTION NORMALLY.
3. Cranes, forklift trucks or other equipment which may be available are to be used to remove platform occupants and stabilize motion of the machine in case machine controls are inadequate or malfunction when used.

Platform Caught Overhead

If the platform becomes jammed or snagged in overhead structures or equipment, do not continue operation of the machine from either the platform or the ground until the operator and all personnel are safely moved to a secure location. Only then should an attempt be made to free the platform using any necessary equipment and personnel. Do not operate controls to cause one or more wheels to leave the ground.

Righting of Tipped Machine

A forklift of suitable capacity or equivalent equipment should be placed under the elevated side of the chassis, with a crane or other suitable lifting equipment used to lift the platform while the chassis is lowered by the forklift or other equipment.

Post-Incident Inspection

Following any incident, thoroughly inspect the machine and test all functions first from the ground controls, then from the platform controls. Do not lift above 10 feet (3 meters) until you are secure that all damage has been repaired, if required, and that all controls are operating correctly.

6. GENERAL SPECIFICATIONS AND OPERATOR MAINTENANCE

6.1 INTRODUCTION

This section of the manual provides additional necessary information to the operator for proper operation and maintenance of this machine.

The maintenance portion of this section is intended as information to assist the machine operator to perform daily maintenance tasks only, and does not replace the more thorough Preventive Maintenance and Inspection Schedule included in the Service and Maintenance Manual.

6.2 OPERATING SPECIFICATIONS

Table 6-1. Operating Specifications

Model	AWPS23.56	AWPS46.79	AWPS46.96
Maximum Stowed Travel Grade (Gradeability)- Refer to Figure 4-1	25%	25%	25%
Maximum Stowed Travel Grade (Sideslope) - Refer to Figure 4-1	2°	2°	2°
Maximum Platform Height	18.4 ft 5.6 m	26 ft 7.9 m	31.5 ft 9.5 m
Maximum Tire Load:	1365 lb (620 kg)	2070 lb (939 kg)	2070 lb (939 kg)
Ground Bearing Pressure	109 psi (7.7 kg/cm ²)	87 psi (6.1 kg/cm ²)	87 psi (6.1 kg/cm ²)
Maximum Drive Speed	2.5 mph (4. kmh)	2.5 mph (4 kmh)	2.5 mph (4 kmh)
Maximum Wind Speed	28 mph (12.5 m/s)	28 mph (12.5 m/s)	28 mph (12.5 m/s)

Table 6-1. Operating Specifications

Model	AWPS23.56	AWPS46.79	AWPS46.96
Maximum Horizontal Manual Side Force:	100 lb force (445 N)	150 lb force (667 N)	150 lb force (667 N)
Maximum Hydraulic Pressure	1800 psi 12.5Mpa	2000 psi 14Mpa	2000 psi 14Mpa
Inside Steer Angle	56°	56°	56°
Outside Steer Angle	42°	42°	42°
Minimum Steer radius	2.5M	3.5M	3.5M
Electrical System Voltage (DC)	24V	24V	24V
Approximate Gross Machine Weight	1390 Kg	2706 Kg	2730 Kg
Lift/down time (S)	28/30	44/50	65/73
Ground Clearance with pot hole protection system down	0.75in (1.9 cm)		
Ground Clearance with pot hole protection system up	3.87 in (9.8cm)	6.19in (12.7cm)	

Table 6-2. Platform Capacities

MODEL	CE		CE Extensions platform	
	Max Capacity	Max Persons	Max Capacity	Max Persons
AWPS23.56	230 kg	2	113 kg	1
AWPS46.79	460 kg	2	113 kg	1
AWPS46.96	460 kg	2	113 kg	1

Dimensional Data

Table 6-3. Dimensions

MODEL	AWPS23.56		AWPS46.79		AWPS46.96	
Unit of Measure	feet	meter	feet	meter	feet	meter
Platform Height - Elevated	18.5	5.6	26	7.9	31.16	9.5
Platform Height - Stowed	3.1	0.96	4	1.2	4	1.2
Working Height	25	7.6	32	9.8	38	11.6
Overall Stowed Machine Height - Rails Up	6.5	2	7.9	2.4	7.9	2.4
Overall Stowed Machine Height - Rails Collapsed	N/A	N/A	6.4	1.9	6.4	1.9
Rail Height (From platform floor)	3.25	1	3.25	1	3.25	1
Overall Machine Width	2.5	0.76	3.8	1.2	3.8	1.2
Overall Machine Length - Deck Retracted	6.2	1.9	8.2	2.5	8.2	2.5
Overall Machine Length - Deck Extended	9	2.8	12.4	3.8	12.4	3.8
Platform Size - Length	6.1	1.9	8.2	2.5	8.2	2.5
Platform Size - Maximum Length	9.11	2.78	12.3	3.75	12.3	3.75
Platform Size - Width	2.5	0.76	3.7	1.1	3.7	1.1
Platform Extension Length	3	0.9	4.2	1.3	4.2	1.3
Wheelbase	5.2	1.6	6.8	2	6.8	2

Motors

Drive Motor

Excitation type : 4 Terminals separate 24V DC Power: 1500w 2600rpm

Figure 6-1 Cricuit diagram


Hydraulic Pump/Electric Motor Assembly (All Models)

Type: Series Wound Permanent Magnet 24V DC Power: 3kW

Batteries

Table 6-4. Battery Specifications

Voltage	6 V per battery
Amp Hour (Standard Battery)	210 Amp



Capacities

Table 6-5. Capacities

Model	AWPS23.56	AWPS46.79	AWPS46.96
Hydraulic Tank	6 L	6 L	7 L
Hydraulic System (Including Tank)	8.3 L	12.5L	14.2L




Figure 6-2 hydraulic principal

Tires

Table 6-6. Tire Specifications

Model	AWPS23.56	AWPS46.79	AWPS46.96
Size	323mm x 100mm	406 mm x 125 mm	
Max Tire Load	2500 lbs (1134 kg)	4000 lbs (1814 kg)	
Wheel Bolt Torque	142-163 Nm		

6.3 CRITICAL STABILITY WEIGHTS



DO NOT REPLACE ITEMS CRITICAL TO STABILITY, SUCH AS BATTERIES OR SOLID TIRES, WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION. DO NOT MODIFY UNIT IN ANY WAY TO AFFECT STABILITY.

Table 6-7. Critical Stability Weights

Component	AWPS23.56	AWPS46.79	AWPS46.96
Wheel and Tire Assembly (each)	22 lbs (9.8 kg)	42 lbs (19 kg)	

Wheel/Tire and Drive Assembly (each)	117 lbs (53 kg)	162 lbs (73.4 kg)	
Lift Cylinder	176 lbs(80 kg)	263 lbs (119 kg)	283 lbs (128 kg)
Batteries: (each) 220 Amp	66 lbs (30 kg)	66 lbs (30 kg)	

Lubrication

NOTE: Aside from recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities.

Please check the oil level every six months. The oil can be hydraulic oil: ISO VG32, its viscosity should be 30cSt at 40⁰ C.

6.4 OPERATOR MAINTENANCE




Figure 6-3. Lubrication Diagram

Oil Check Procedure (1)


Lube Point(s) - Fill Plug Lube - Hydraulic Oil Interval - Every 6 months

1. With the scissor lift on a flat and level surface and the platform empty, elevate machine and swing safety prop out of it's stowed position.
2. Continue to elevate the platform until the fill plug, located on the right side of the tank attached to the lift cylinder, is fully accessible.
3. Wipe all dirt and debris from the filler plug area.

4. Slowly remove the fill plug venting any pressure that may be built up in the reservoir.

5. To check the oil level, lower platform so it rests on the safety prop. The use of level gauge check the hydraulic oil level, when the oil level in H and L between, hydraulic oil quantity in a suitable range.

Vehicle type	H	L
AWPS23. 56	8. 3L	7. 8L
AWPS46. 79	12. 5L	12L
AWPS46. 96	14. 2L	13. 7L



⚠ CAUTION

ENSURE THE SCISSOR ARMS ARE PROPERLY SUPPORTED

NOTE: The AWPS46.79/AWPS46.96 platforms will have to be raised higher than the AWPS23.56 in order to access the oil plug.

⚠ CAUTION

THERE MAY BE UP TO 10 PSI OF PRESSURE IN THE TANK.

⚠ CAUTION

First come on, can mix oil tank filled with, and then pick up platform about 2 ~ 3 meters or so, continue refueling. Oil capacity can see table 6-5 capacity.

6. With the plug removed, the oil level should be completely full, at the top of the fill port with scissor arms resting on the safety prop. from the fill port.

7. If additional oil is required, add proper grade of oil by using a funnel with a flexible spout or a plastic squeeze bottle. Fill until oil weeps out of opening.

NOTE: Care should be taken not to introduce any impurities (dirt, water etc.) while plug is removed.

8. Replace plug and torque to 40 ft lbs (56 Nm).

9. Any time a hydraulic component is removed or replaced, cycle the scissor arms several times and refer to steps 3 and 4 to recheck oil level.

Lower (2) & Upper Slide Pads (3)

Lube - White Lithium Grease
Interval - Every 6 months

1. With the platform empty, elevate machine and swing safety prop out of it's stowed position.



ENSURE THE SCISSOR ARMS ARE PROPERLY SUPPORTED.

2. Locate the Lower and Upper Slide Pads and remove all dirt and debris from the slide channel area (1, 2). Refer to Figure 6-2., Lower Slide Pad Channel.
3. Apply a layer of grease along the inside and bottom of the lower slide channel (1) on both sides of the machine.




Figure 6-2. Lower Slide Pad Channel




Figure 6-3. Upper Slide Pad Channel

4. Apply a layer of grease along the inside and top of the upper slide channel (2) on both sides of the machine. Refer to Figure 6-3., Upper Slide Pad Channel.

NOTE: *Recommended lubricating intervals are based on machine operations under normal conditions. For machines used in multi-shift operations and/or exposed to hostile environments or conditions, lubrication frequencies must be increased accordingly.*

6.5 TIRES AND WHEELS

Tire Wear and Damage

Inspect tires periodically for wear or damage. Tires with worn edges or distorted profiles require replacement. Tires with significant damage in the tread area or side wall, require immediate evaluation before placing the machine into service.

Wheel and Tire Replacement

Replacement wheels must have the same diameter and profile as the original. Replacement tires must be the same size and rating as the tire being replaced.

Wheel Installation

It is extremely important to apply and maintain proper wheel mounting torque.

⚠ WARNING

WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.
2. Tighten nuts in the following sequence.
3. The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque.




Table 6-9. Wheel Torque Chart

TORQUE SEQUENCE		
1st Stage	2nd Stage	3rd Stage
20-30 ft lbs (28 - 42 Nm)	65-80 ft lbs (91 - 112 Nm)	105 -120 ft lbs (142 - 163 Nm)

4. Wheel nuts should be torqued after the first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

The general moments for screwing the hydraulic hose

Thread	Nut Torque (N·m)
M14×1.5	20.7~25.3


Appendix 1 list of wearing parts

No.	No.	Name	Quantity	Respective components
1	0000022036	Combination washer 12	2	Valve board components
2	0090000087	O-Shaped ring 7.5x1.8	2	
3	0000025021	Combination washer 10	10	
4	0090000156	O-Shaped ring 8x2.65	2	
5	9000001355	O-Shaped ring 94.84x3.53	1	Lifting cylinder
6	9000001356	Guide ring 60x65x9.7	2	

7	9000001357	Y shape circle 60x70x10	1	
8	9000001358	dust ring 60x68x5/6.5	1	
9	0000022040	O-Shaped ring 35x3.1	1	
10	9000001359	Supporting ring 100x95x9.7	2	
11	9000001360	Sealing ring100x87x8.3	1	
12	9000001361	dust ring 35/43X5/38	2	Steering cylinders
13	9000001362	Sealing ring35/45X8	2	
14	9000001363	O-Shaped ring 53.57X3.53	2	
15	9000001364	Block circle	2	
16	9000001365	Sealing ring60/49X4.2	1	
17	9000001366	O-Shaped ring 34.59X2.62	1	
18	9000001367	Block circle	1	
19	9000002219	O-Shaped ring	2	pump
20	9000002236	O-Shaped ring	1	
21	9000002240	Sealing ring	1	
22	9000002247	Sealing ring	1	
23	9000002249	Sealing ring	1	
24	9000002251	Sealing ring	1	
25	9000002252	Sealing ring	1	
26	9000002256	Sealing ring	1	
27	9000002263	filter	1	
28	0090000159	Tapered roller bearings 32209	2	chassis
29	0090000160	Tapered roller bearings 32206	2	

Appendix 2 Inspection and maintenance records

Date	Note



Parts & Components Manual

AWPS23.56/AWPS46.79/AWPS46.96

Electric scissor lifts

Zhejiang Noblelift Equipment Joint Stock Co.,Ltd

Contents

Figure 1.1	Parts and components of platform (AWPS2356)	2
Figure 1.2	Parts and components of platform (AWPS2356-G)	5
Figure 1.3	Parts and components of platform (AWPS4679、AWPS4696)	7
Figure 1.4	Parts and components of platform (AWPS4679-G、AWPS4696-G)	10
Figure 2.1	Parts and components of scissors (AWPS2356)	12
Figure 2.2	Parts and components of scissors (AWPS4679、AWPS4696)	14
Figure 3.1	Parts and components of chassis (AWPS2356)	16
Figure 3.2	Parts and components of chassis (AWPS4679、AWPS4696)	19
Figure 3.3	Side supporting device (AWPS2356)	22
Figure 3.4	Side supporting device (AWPS4679、AWPS4696)	24
Figure 4	Steering cylinder	26
Figure 5.1	Lifting cylinder (AWPS2356)	28
Figure 5.2	Lifting cylinder (AWPS4679、AWPS4696)	30
Figure 6	Parts and components of pump station	32
Figure 7.1	Electrical parts (AWPS2356)	35
Figure 7.2	Electrical parts (AWPS4679、AWPS4696)	38
Figure 7.3	Platform electrical box (AWPS2356)	41
Figure 7.4	Platform electrical box (AWPS4679、AWPS4696)	43
Figure 7.5	Chassis electrical box	45
Figure 7.6	Parts and components of aluminum plate	46

Figure 1.1 Parts and components of platform (AWPS2356)




Figure 1.1 Parts and components of platform (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	9000001740	Left-extended steel welding	1	
2	9000001742	Right-extended steel welding	1	
3	0000024104	Locking nut	2	
4	9000001378	Snap	2	
5	9000001463	Handle guard board	1	
6	9000001440	Lever welding	2	
7	9000001443	Rubber sleeve	2	
8	0000024045	Locking nut	6	
9	0090000136	Hex head bolt	4	
10	9000001452	Nylon sleeve	2	
11	0000023427	Hex head bolt	2	
12	0000023081	Locking nut	6	
13	9000001748	Square tube	1	
14	9000001730	Left fence welding	1	
15	9000001735	Right fence welding	1	
16	0000023665	Hex head bolt	4	
17	9000001743	Extension rod	2	
18	0090000128	Core pulling rivet	30	
19	9000001747	Upper hanging plate	1	
20	9000001749	Lower hanging plate	1	
21	9000001726	Front fence welding	1	
22	0000023737	Hex head bolt	2	
23	9000001459	Spring hinge	2	
24	9000001736	Door frame welding	1	
25	0000023870	Hex head bolt	2	
26	9000001813	Upper axis slider	2	
27	0000024097	Locking nut	26	
28	0090000139	Screw	12	
29	0000025106	Flat washer	22	
30	9000001712	Outer platform welding	1	
31	9000001456	Nylon wheel	4	
32	9000001746	Right scroll wheel guard	1	
33	9000001745	Left scroll wheel guard	1	
34	9000001744	Wheel axle welding	4	
35	0090000139	Screw	8	

36	0000023794	Hex head bolt	4	
37	9000001461	U-shaped block	2	
38	9000001721	Extended platform welding	1	
39	9000001901	Door lock	1	
40	0090000163	Screw	2	
41	9000001902	Tongue bars	1	

Figure 1.2 Parts and components of platform (AWPS2356-G)




Figure 1.2 Parts and components of platform (AWPS2356-G)

No.	Part Number	Name	Quantity	Remarks
1	9000001883	Outer platform welding (fixed)	1	
2	9000001748	Square tube	1	
3	9000001736	Door frame welding	1	
4	0090000128	Core pulling rivet	28	
5	9000001459	Spring hinge	2	
6	9000001747	Upper hanging plate	1	
7	9000001749	Lower hanging plate	1	
8	0000023870	Hex head bolt	2	
9	9000001813	Upper axis slider	2	
10	0000024097	Locking nut	12	
11	0090000139	Screw	12	
12	0000025106	Flat washer	12	
13	9000001901	Door lock	1	
14	0090000163	Screw	2	
15	0000024104	Locking nut	2	
16	9000001902	Tongue bars	1	
17	9000001463	Handle guard board	1	

Figure 1.3 Parts and components of platform (AWPS4679、AWPS4696)




Figure 1.3 Parts and components of platform (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	9000001414	Left-extended steel welding	1	
2	9000001417	Right-extended steel welding	1	
3	0000024104	Locking nut	2	
4	9000001378	Snap	2	
5	9000001463	Handle guard board	1	
6	9000001440	Lever welding	2	
7	9000001443	Rubber sleeve	2	
8	0000024045	Locking nut	22	
9	0090000124	Hex head bolt	20	
10	9000001452	Nylon sleeve	2	
11	0090000146	Hex head bolt	2	
12	0000023081	Locking nut	2	
13	9000001457	Upper edge of door frame	1	
14	9000001406	Upper fence welding	2	
15	9000001444	Components of wire sleeve	6	
16	9000001412	Upper-front fence welding	1	
17	9000001447	Doorframe column welding	2	
18	9000001448	Square tube	4	
19	9000001451	Square tube	2	
20	0090000128	Core pulling rivet	40	
21	9000001458	Hanging plate	1	
22	9000001394	Lower-left fence welding	1	
23	9000001401	Lower-right fence welding	1	
24	9000001459	Spring hinge	2	
25	9000001403	Door frame welding	1	
26	9000001460	Extension rod	2	
27	9000001409	Lower-front fence welding	1	
28	0000023737	Hex head bolt	2	
29	0090000126	Hex head bolt	2	
30	9000001531	Upper axis slider	2	
31	0000024097	Locking nut	30	
32	0090000139	Screw	28	
33	0000025106	Flat washer	26	
34	9000001453	Wheel axle welding	4	
35	9000001443	Nylon wheel	4	

36	9000001379	Platform welding	1	
37	9000001389	Extended platform welding	1	
38	0000023794	Hex head bolt	4	
39	9000001461	U-shaped block	2	
40	9000001901	Door lock	1	
41	0090000163	Screw	2	
42	9000001464	Tongue bars	1	

**Figure 1.4 Parts and components of platform (AWPS4679-G,
AWPS4696-G)**




Figure 1.4 Parts and components of platform (AWPS4679-G 、AWPS4696-G)

No.	Part Number	Name	Quantity	Remarks
1	9000001457	Upper edge of door frame	1	
2	9000001703	Upper fence welding (fixed)	1	
3	0000024045	Locking nut	18	
4	0090000124	Hex head bolt	18	
5	9000001463	Handle guard board	4	
6	9000001378	Snap	2	
7	9000001464	Tongue bars	1	
8	9000001441	Lever	2	
9	9000001443	Rubber sleeve	2	
10	9000001444	Components of wire sleeve	6	
11	9000001447	Doorframe column welding	2	
12	9000001448	Square tube	4	
13	9000001451	Square tube	2	
14	9000001458	Hanging plate	1	
15	0090000128	Core pulling rivet	40	
16	9000001705	Lower fence welding (fixed)	1	
17	9000001403	Door frame welding	1	
18	9000001459	Spring hinge	2	
19	0090000126	Hex head bolt	2	
20	9000001531	Upper axis slider	2	
21	0000024097	Locking nut	20	
22	0090000139	Screw	18	
23	0000025106	Flat washer	18	
24	9000001699	Platform welding (fixed)	1	
25	9000001901	Baffle lock	1	
26	0090000163	Screw	2	

Figure 2.1 Parts and components of platform (AWPS2356)




Figure 2.1 Parts and components of platform (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	9000001813	Upper axis slider	2	
2	9000001773	Lower inner lifting fork	1	
3	9000001765	Lower outer lifting fork	1	
4	9000001784	Upper second inner lifting fork	1	
5	9000001782	Upper second outer lifting fork	1	
6				
7	9000001786	Lower outer lifting fork	1	
8	9000001793	Upper inner lifting fork	1	
9	9000001533	Compound sleeve	4	
10	0000027006	Compound sleeve	28	
11	9000001812	Supporting plate	1	
12	9000001811	Cable fixing plate	1	
13	0090000004	Hex head bolt	17	
14	0000024003	Locking nut	17	
15	9000001549	Buffer cushion	12	
16	9000001804	Scissor connection axis (a)	10	
17	9000001807	Scissor connection axis (c)	4	
18	9000001806	Scissor connection axis (b)	1	
19	9000001805	Supporting plate axis	1	
20	0000026013	Spring washer	14	
21	9000001809	Long connection axis	1	
22	9000001808	Gasket	14	
23	9000001866	Cylinder components	1	
24	0090000133	Cotter pin	2	
25	0000025106	Gasket	2	
26	9000001810	Lower slider	2	

Figure 2.2 Parts and components of scissors (AWPS4679、AWPS4696)




Figure 2.2 Parts and components of scissors (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	9000001466	Lower outer scissor	1	
2	9000001472	Lower inner scissor	1	
3	9000001484	Upper second outer scissor (1)	1	
4	9000001489	Upper second inner scissor	1	
5	9000001494	Upper third outer scissor	1	
6	9000001496	Upper third inner scissor	1	
7	9000001508	Upper inner scissor	1	
8	9000001502	Upper outer scissor	1	
9	9000001533	Compound sleeve	4	
10	9000001536	Cylinder connection shaft	1	
11	0000025002	Gasket	1	
12	9000001545	Cable fixing plate	2	
13	0000025002	Gasket	4	
14	0090000133	Cotter pin	4	
15	0000023658	Hex head bolt	5	
16	9000001535	Retaining pin	1	
17	0000023005	Locking nut	34	
18	9000001534	Top wheel axle	1	
19	9000001514	Supporting arm	1	
20	9000001544	Supporting wheel	1	
21	0090000129	Hex head bolt	25	
22	9000001528	Scissor connection axis	19	
23	9000001529	Compound sleeve	42	
24	9000001530	Gasket	20	
25	0000026042	Spring washer	20	
26	0090000131	Hex head bolt	2	
27	9000001540	Connecting shaft	1	
28	9000001547	Supporting plate	1	
29	9000001531	Upper axis slider	2	
30	9000001543	Long connection axis	1	
31	9000001546	Lower slider	2	
32	9000001549	Buffer cushion	14	
33	9000001488	Upper second outer scissor (2)	1	

Figure 3.1 Parts and components of chassis (AWPS2356)




Figure 3.1 Parts and components of chassis (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	9000001815	Chassis	1	
2	0000023055	Flat washer	2	
3	0000023053	Screw	3	
4	9000001597	Round-shaped dust-proof cover	4	
5	0000028070	Cotter pin	2	
6	0000023658	Hex head bolt	8	
7	0000023495	Hex head bolt	4	
8	0000025002	Flat washer	12	
9	9000001873	Steering cylinder	1	
10	9000001600	Steering connecting rod pin	4	
11	9000001599	Steering connecting rod	2	
12	0000026079	Open retainer ring	4	
13	9000001589	Thrust washer	2	
14	9000001590	Composite sleeve	4	
15	9000001859	Driving wheel frame	2	
16	9000001591	Gasket	2	
17	0000026069	Spring washer	2	
18	9000001157	traction motor	2	
19	9000001844	Wheel	2	
20	9000001593	Wheel bolt	10	
21	9000001640	Baffle plate	4	
22	0000023040	Screw	4	
23	9000002347	Battery case welding	1	
24	9000001629	Battery cover	1	
25	9000001635	Compression lock	4	
26	0000023055	Flat washer	8	
27	0000023519	screw	8	
28	9000001863	Chassis electrical box cover	1	
29	9000001598	Rotary shaft lip type seals	2	
30	0090000159	Bearing	2	
31	9000001594	Wheel hub connection disk	2	
32	0090000160	Bearing	2	
33	0090000109	Flat washer	4	

34	0090000134	Nut	2	
----	------------	-----	---	--

Figure 3.2 Parts and components of chassis (AWPS4679、AWPS4696)




Figure 3.2 Parts and components of chassis (AWPS4679、AWPS4696)

No.	Part Number	Part Name	Quantity	Remarks
1	9000001552	Chassis	1	
2	9000001607	Balance weight	1	
3	9000001606	Balance weight	1	
4	0000023004	Hex head bolt	2	
5	0090000135	Big washer	4	
6	0000023005	Locking nut	16	
7	0000023374	Hex head bolt	2	
8	0000023862	Pan head screw	11	
9	0000023055	Flat washer	15	
10	9000001601	Cover plate	1	
11	0000023495	Hex head bolt	4	
12	0000025106	Flat washer	14	
13	9000001686	Steering cylinder	1	See Figure 6
14	9000001600	Steering connecting rod pin	4	
15	9000001599	Steering connecting rod	2	
16	0000026079	Open retainer ring 9	4	
17	9000001589	Thrust washer	2	
18	9000001590	Compound sleeve	4	
19	9000001586	Steering wheel seat	2	
20	9000001591	Gasket	2	
21	0000026069	Spring washer	2	
22	9000001598	Bearing dust-proof ring	2	
23	0090000159	Bearing	2	
24	9000001594	Rim connection disk	2	
25	0090000160	Bearing	2	
26	9000001592	Wheel	4	
27	9000001593	Wheel bolt	20	
28	0090000109	Flat washer	4	
29	0090000134	Nut	2	
30	9000001597	Round-shaped dust-proof cover	4	
31	0000028070	Cotter pin	2	
32	9000001640	Baffle plate	4	
33	0000023040	Screw	4	

34	9000001630	Battery case welding	1	
35	9000001629	Battery hood	1	
36	0000023055	Flat washer	12	
37	0000023519	Pan head screw	12	
38	9000001635	Compression lock	4	
39	0090000132	Hex head bolt	4	
40	9000001617	Connecting plate	1	
41	0000024045	Locking nut	4	
42	9000001626	Drive axle cover	2	
43	9000001627	Drive axle cover	2	
44	9000001625	Drive axle connecting shaft	1	
45	9000001535	Retaining pin	1	
46	0000023526	Screw	1	
47	0000025065	Spring washer 10	1	
48	9000001618	Drive axle	1	
49	9000001595	Rim connection disk	2	
50	9000001637	Compound set	2	
51	9000001648	shields	1	

Figure 3.3 Side supporting device (AWPS2356)




Figure 3.3 Side supporting device (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	0000023658	Hex head bolt	4	
2	0000023005	Locking nut	4	
3	0000025106	Gasket	4	
4	9000001800	Bracket	1	
5	0000026013	Spring washer	2	
6	9000001526	Spring	2	
7	9000001525	Steering rod	2	
8	9000001527	Top sleeve	2	
9	9000001860	Side supporting plate welding	2	
10	9000001613	Pin roll of supporting plate	4	
11	0000026013	Spring washer	12	
12	9000001851	Rocker	1	
13	9000001857	Pin roll of connecting plate	2	
14	9000001616	Swinging block axis	2	
15	9000001858	Pin roll of connecting rod	4	
16	9000001859	Side supporting rod	2	
17	9000001847	Connecting plate for lifting	1	

Figure 3.4 Side supporting device (AWPS4679、AWPS4696)




Figure 3.4 Side supporting device (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	0000023658	Hex head bolt	4	
2	0000023005	Locking nut	4	
3	0000025106	Gasket	4	
4	9000001520	Bracket	1	
5	0000026013	Spring washer	2	
6	9000001526	Spring	2	
7	9000001525	Steering rod	2	
8	9000001527	Top sleeve	2	
9	9000001608	Side supporting plate welding	2	
10	9000001613	Pin roll of supporting plate	4	
11	0000026013	Spring washer	12	
12	9000001615	Swing block	2	
13	9000001614	Pin roll of connecting rod	2	
14	9000001616	Swinging block axis	2	
15	9000001643	Pin roll	2	
16	9000001646	Spring	2	
17	9000001647	Top axis	2	
18	9000001644	Connecting rod	2	
19	9000001645	Connecting rod	4	
20	9000001643	Pin roll	2	
21	0000026019	Spring washer	4	

Figure 4. Steering cylinder




Figure 4. Steering cylinder

No.	Part Number	Part Name	Quantity	Remarks
1	9000001366	O-shaped ring	2	
2	9000001363	O-shaped ring	2	
3	9000001364	Retainer ring	2	
4	9000001362	Seal ring for rod	2	
5	9000001361	Dust-proof ring	2	
6	9000001365	Seal ring for hole	1	
7	9000001688	Stopping tube	2	AWPS4679
	9000001874			AWPS2356
8	9000001367	Retainer ring for shaft	1	
9	9000001673	Oil tube connector	2	
10	9000001691	Cylinder	1	AWPS4679
	9000001876			AWPS2356
11	9000001689	Piston rod	1	AWPS4679
	9000001875			AWPS2356
12	9000001687	Steering tube	2	
13	9000001690	Piston	1	

Figure 5.1 Lifting cylinder (AWPS2356)




Figure 5.1 Lifting cylinder (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	0000027006	Compound sleeve	2	
2	9000001868	Piston rod	1	
3	0000022099	O-shaped ring	1	
4	9000001371	Dust-proof ring	1	
5	9000001370	Y-shaped ring for axis	1	
6	9000001869	Nut cap	1	
7	9000001368	O-shaped ring	1	
8	9000001369	Guide ring	2	
9	9000001870	Piston	1	
10	0090000110	Hexagon nut	1	
11	9000001372	Piston support ring	2	
12	9000001373	Seal ring for hole	1	
13	9000001867	Cylinder body	1	
14	0090000155	Elastic cylindrical pin	1	
15	9000001681	Spring	1	
16	0000027006	Compound sleeve	2	
17	0000024099	Hexagon nut	1	
18	9000001678	Pull string	1	
19	9000001680	Pendulum	1	
20	0000028160	Elastic cylindrical pin	1	
21	9000001679	Pendulum holder	1	
22	9000001670	Lowering solenoid valve	1	
23	9000001672	Balancing valve of steering cylinder	1	
24	9000002218	Pump station	1	See Figure 6

Figure 5.2 Lifting cylinder (AWPS4679、AWPS4696)




Figure 5.2 Lifting cylinder (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	9000001664	Compound sleeve	2	
2	9000001662	Piston rod	1	
3	0000022040	O-shaped ring	1	
4	9000001358	Dust-proof ring	1	
5	9000001357	Y-shaped ring for axis	1	
6	9000001663	Cap nut	1	
7	9000001355	O-shaped ring	1	
8	9000001356	Guide ring	2	
9	9000001665	Piston	1	
10	0090000149	Hexagon nut	1	
11	9000001359	Piston support ring	2	
12	9000001360	Seal ring for hole	1	
13	9000001661	Cylinder body	1	
14	0090000155	Elastic cylindrical pin	1	
15	9000001681	Spring	1	
16	0000027006	Compound sleeve	2	
17	0000024099	Hexagon nut	1	
18	9000001678	Pull string	1	
19	9000001680	Pendulum	1	
20	0000028160	Elastic cylindrical pin	1	
21	9000001679	Pendulum holder	1	
22	9000001670	Lowering solenoid valve	1	
23	9000001672	Balancing valve of steering cylinder	1	
24	9000001692	Pump station (AWPS4696)	1	See Figure 6
	9000002217	Pump station (AWPS4679)		

Figure 6 Parts and components of pump station




Figure 6 Parts and components of pump station

No.	Part Number	Name	Quantity	Remarks
1	9000002219	O-shaped ring	2	
2	9000002220	Bolt	1	
3	9000002221	Lock nut	1	
4	9000002222	Bolt	4	
5	9000002223	Gasket	2	
6	9000002224	Hoop	1	
101	9000002225	Cylinder	1	AWPS4696
	9000002226			AWPS4679
	9000002226			AWPS2356
101A	9000002227	Refuelling plug	1	
101B	9000002228	Bolt	4	
101C	9000002229	Magnet	1	
102A	9000002230	Motor	1	AWPS4696
	9000002230			AWPS4679
	9000002231			AWPS2356
102B	9000002232	Bolt	2	
102C	9000002233	Motor	1	
102D	9000002234	Bolt	4	
103	9000002235	Valve body	1	
103A	9000002236	O-shaped ring	1	
103B	9000002237	Bolt	1	
103C	9000002238	Bolt	1	
103D	9000002239	Adapter	1	
103E	9000002240	Seal ring	1	
103F	9000002241	Stopper	1	
103G	9000002242	Screw plug	1	
103H	9000002243	Screw plug	1	
103J	9000002244	Ventilation valve	1	
103K	9000002245	Ventilation valve	1	

104	9000002246	Gear pump	1	
104A	9000002247	Seal ring	1	
105	9000002248	Components of safety valve	1	
105A	9000002249	Seal ring	1	
106	9000002250	Power box	1	
106A	9000002251	Seal ring	1	
106B	9000002252	Seal ring	1	
106C	9000002253	Bolt	1	
106D	9000002254	Sleeve	1	
106E	9000002255	Spring pin	1	
106F	9000002256	Seal ring	1	
106G	9000002257	Locking tab	1	
106H	9000002258	Stopper	1	
106J	9000002259	Coupling	1	
106K	9000002260	Bolt	1	
107	9000002261	Oil tube	1	
107A	9000002262	Filter	1	
107B	9000002263	Filter core	1	

Figure 7.1 Electrical parts (AWPS2356)




Figure 7.1 Electrical parts (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	9000001751	platform electrical box	1	
2	9000001636	Battery	4	
3	1020434006	Socket connector	2	
4	0000023090	Screw	2	
5	9000001639	Charger	1	
6	0000023055	Flat washer	6	
7	0000023053	Screw	5	
8	0000023042	Screw	1	
9	0000023055	Flat washer	1	
10	3002434013	Reversing	1	
11	9000001846	ACCESS Controller	1	
12	0000023688	Screw	2	
13	9000001856	Safety limit switch	2	
14	9000001638	Switch holder	2	
15	1000434015	Horn	1	
16	0090000241	Screw	2	
17	0000023020	Screw	2	
18	9000002340	Weighing transmitter	1	
19	0000025019	Flat washer	4	
20	0000025018	Spring washer	4	
21	0000023538	Pan head screw	4	
22	0000023904	Hex head bolt	4	
23	9000001532	Weighing sensor	4	
24	0000023005	Locking nut	4	
25	9000002341	Driver module ACCESS	1	
26	0000023315	Screw	2	
27	0000025002	Flat washer	2	
28	9000002344	Limit switch fixed plate	1	
29	0090000242	Screw	2	

30	0000024045	Locking nut	2	
31	0090000241	Screw	2	
32	9000002342	Limit switch	1	

Figure 7.2 Electrical parts (AWPS4679、AWPS4696)




Figure 7.2 Electrical parts (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	9000001418	platform electrical box	1	
2	9000001636	Battery	4	
3	9000001158	Geared Motor	2	
4	1020434006	Socket connector	2	
5	0000023090	Hexagon	2	
6	9000001639	Charger	1	
7	0000023055	Flat washer	4	
8	0000023040	Screw	4	
9	9000002343	Tilt sensor	1	
10	0000025014	Flat washer	2	
11	0000023076	Screw	2	
12	0000023042	Screw	1	
13	0000023055	Flat washer	1	
14	3002434013	Reversing buzzer	1	
15	9000001651	chassis electrical operation box	1	
16	0000025010	Spring washer	3	
17	0000023055	Flat washer	3	
18	0000023020	Screw	3	
19	9000002342	Limit switch	1	
20	0000025019	Flat washer	2	
21	0000023307	Pan head screw	2	
22	9000001602	Electrical installation board	1	
23	0000023055	Flat washer	4	
24	0000023030	Screw	4	
25	1000434015	Horn	1	
26	0000023055	Flat washer	1	
27	0000023040	Screw	1	
28	9000002340	Weighing transmitter	1	
29	0000025019	Flat washer 4	4	
30	0000025018	Spring washer 4	4	

31	0000023538	Pan head screw	4	
32	0090000131	Hex head bolt	4	
33	9000001532	Weighing sensor	4	
34	0000023005	Locking nut	4	
35	9000001856	Safety limit switch	2	
36	9000001638	Switch seat	2	
37	0000023090	Screw	4	
38	0000023055	Flat washer	4	
39	0000024045	Nut	4	
40	0090000241	Screw	4	
41	9000001649	Fixed board	1	
42	0000023041	Pan head screw	2	
43	0000024004	Locking nut	2	
44	0000024045	Locking nut	2	
45	0090000241	Screw	2	
46	9000002342	Limit switch	1	
47	9000002344	Fixed plate	1	
48	0000025002	Flat washer	2	
49	0090000242	Screw	2	

Figure 7.3 Platform electrical box (AWPS2356)




Figure 7.3 Platform electrical box (AWPS2356)

No.	Part Number	Name	Quantity	Remarks
1	0000023516	Pan head screw	6	
2	0000025014	class flat washer	6	
3	9000001758	Welding of hanging plat	1	
4	9000001432	Button switch	2	
5	9000001431	Button switch	1	
6	9000001752	platform electrical box	1	
7	0000023071	Pan head screw	4	
8	9000001761	JIM display board	1	
9	9000001429	Operational lever	1	
10	1010434024	Emergency stop switch	1	
11	9000001433	Outlet	1	
12	0000023573	Pan head screw	4	
13	9000001434	Plug	1	
14	9000001762	Spring line	1	

Figure 7.4 Platform electrical box (AWPS4679、AWPS4696)




Figure 7.4 Platform electrical box (AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	0000023534	Pan head screw	20	
2	0000023032	Flat washer	22	
3	9000001419	Left plate	1	
4	1010434024	Emergency stop switch	1	
5	9000001421	Welding of the rear box	1	
6	9000001437	Lever cover	1	
7	9000001438	Front cover plate	1	
8	9000001425	Welding of the front box	1	
9	9000001432	Button switch	1	
10	9000001430	Metal lamp	2	
11	9000000760	Instrument	1	
12	9000001431	Button switch	1	
13	9000001435	Buzzer	1	
14	9000001429	Operation lever	1	
15	9000001420	Right plate	1	
16	0000023574	Pan head screw	2	
17	0000023573	Pan head screw	4	
18	9000001436	Spring line	1	
19	0000024017	Hexagon nut	4	
20	0000025009	Elastic cushion	4	
21	9000001439	Logic board	1	
22	2240403001	White column	4	
23	0000023538	Pan head screw	4	
24	0000023716	Pan head screw	3	
25	9000001433	Outlet	1	
26	9000001434	Plug	1	

Figure 7.5 Chassis electrical box (AWPS4679、AWPS4696)




Figure 7.5 Chassis electrical box (AWPS4679、AWPS4696)

No.	Part Number	Name	Quantity	Remarks
1	9000001651	chassis electrical operation box	1	
2	9000001660	Rear cover plate	1	
3	0090000041	Screw	4	
4	9000001430	Metal lamp	1	
5	9000001430	Metal lamp	1	
6	1070334006	Button switch	1	
7	9000001659	Key switch	1	
8	9000001658	Button switch	1	
9	1010434024	Emergency stop switch	1	

Figure 7.6 Components of aluminium plate




Figure 7.6 Components of aluminium plate

No.	Part Number	Name	Quantity	Remarks
1	9000001604	Electrical installation board	1	
2	9000001603	Controller	1	
3	0000023020	Hexagon	4	
4	0000025010	Elastic pad	4	
5	0000023055	Flat pad	4	
6	0000023076	Pan head screw	2	
7	0000025015	Elastic pad	2	
8	0000025014	Flat pad	2	
9	9000001605	Contactor mounting plate	1	
10	0000023716	Pan head screw	4	
11	2390434003	Contactor	1	
12	1000434007	Fuse holder	1	
13	0000025008	Flat pad	6	
14	0000025009	Elastic pad	6	
15	0000023211	Pan head screw	2	
16	1020434001	Bolted fuse	1	
17	0000023016	Pan head screw	2	
18	1000434036	Relay	1	
19	0000023019	Pan head screw	2	
20	1000434009	Two-position fuse seat designed for automobile	1	
21	1000434040	Blade fuse	2	