

FEATURES SHEET

Deluxe Instrumentation

Quickly read operation information including the fuel level, coolant temperature, day / time, throttle position, engine RPM and more on easy-to-read virtual gauges. Also control auxiliary flow modes and rates and view diagnostic information and service internal reminders. An integrated keyless start system is included.

Angle Blade

Places spoil accurately with simultaneous up / down and angle adjustments, up to 25 degrees left or right; bolt-on, reversible cutting edge provides long life and easy replacement.

Cab with Heat and A/C

Work in comfort with air movement, temperature control and greater flexibility in directing air. Choose a cab with heat, A/C or heat and A/C.

Eco-Mode

Machines with deluxe instrumentation include an eco-mode option that limits RPM and can increase fuel efficiency.

Radio

Listen to music while you work with the conveniently placed radio, which includes an audio input to connect an MP3 player or other device.

Deluxe Cloth Seat

Get the most comfort and support with a cloth seat.

Keyless Start

Forget about losing or forgetting your keys. Start your machine with a programmable access code. Learn all the benefits in the Bobcat Advantage Keyless Start video.

Steel Tracks

Equip your machine to withstand the toughest ground conditions.

Travel Motion Alarm

Alert other workers on the jobsite when your excavator is traveling.

Hydraulic X-Change™ Quick-Tach System

Enables fast attachment changes through a switch that activates hydraulic pins for attachment removal or hook-up.

Hydraulic Clamp Attachment

Get better control when moving odd-shaped objects and debris. Install the clamp through an auxiliary port relief on the closed center valve.

Secondary Auxiliary Hydraulics

Operate the rotating clamshell or grapple attachments.

Long Arm with Add-On Counterweight

Reach further and do more work before you have to reposition the machine.

Extendable Arm with Add-On Counterweight

Reach an additional 30 inches at full extension while maintaining the ability to operate with standard reach which retains original arm and bucket forces. In addition, the structure provides compatibility with the clamp attachment as well as the Hydraulic X-Change™ mounting system.

Approved Attachments

- Auger
- Buckets
- Clamp
- Grading blade
- Grapple, 3-tined
- Hydra-Tilt™ swing accessory
- Breaker
- Packer wheel
- Plate compactor
- PowerTilt® swing accessory

- Ripper